



## MultiConnect® Conduit™ Starter Kit For LoRa® Technology Getting Started Guide

### MultiConnect Conduit Starter Kit for LoRa Technology

Part Number: 82102251L

#### Copyright

This publication may not be reproduced, in whole or in part, without the specific and express prior written permission signed by an executive officer of Multi-Tech Systems, Inc. All rights reserved. **Copyright © 2016 by Multi-Tech Systems, Inc.**

Multi-Tech Systems, Inc. makes no representations or warranties, whether express, implied or by estoppels, with respect to the content, information, material and recommendations herein and specifically disclaims any implied warranties of merchantability, fitness for any particular purpose and noninfringement. Multi-Tech Systems, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Multi-Tech Systems, Inc. to notify any person or organization of such revisions or changes.

#### Trademarks and Registered Trademarks

MultiTech, and the MultiTech logo, and MultiConnect are registered trademarks and mDot and Conduit are a trademark of Multi-Tech Systems, Inc. All other products and technologies are the trademarks or registered trademarks of their respective holders.


#### World Headquarters

Multi-Tech Systems, Inc.  
2205 Woodale Drive, Mounds View, MN 55112  
Phone: (800) 328-9717 or (763) 785-3500  
Fax (763) 785-9874

## MultiConnect® Conduit™ Starter Kit for LoRa Technology

The MultiConnect Conduit Starter Kit for LoRa Technology provides everything needed to rapidly get your LoRa proof of concept up, running and connected to the cloud – all in one box. The Starter Kit is designed to enable you to obtain sensor information and display it in the cloud within minutes of opening the box.

### Starter Kit Products



Item	Device	Quantity
1	Conduit	1
2	LoRa Accessory mCard	1
3	mDot	2

Item	Device	Quantity
4	mDot Universal Developer Kit	1
5	mDot Micro Developer Kit	1
6	mDot Box	1

#### Notes:

- The LoRa Accessory mCard is pre-installed in your Conduit.
- Package contents for each device are listed in that device's Quick Start.

### Preparing the Conduit

The Conduit comes pre-configured with Node-RED flow to send data from the mDot Box to the IBM Bluemix site.

To get started with Conduit:

1. Attach the power blades for your country to the power supply and connect the power supply to Conduit.
2. Attach a LoRa antenna to the LoRa Accessory mCard installed in the Conduit.
3. Plug in the Conduit to power it up.
4. Use the Ethernet connector to connect the Conduit to a device with Internet access that you will use to administer the Conduit.
5. Go to the AEP interface and log into the Conduit. To do this:
  - a. Open an Internet browser and enter the device's default address: <http://192.168.2.1>.
  - b. Enter the default user name: **admin**.
  - c. Enter the default password: **admin**.
  - d. Click **Login** to start the First Time Setup Wizard.
6. Use the Wizard to configure the following settings:
  - Password
  - Date and time
  - PPP (Cellular models)
  - IP Address and Network information (Select WAN mode for non-cellular models)

For more information on configuring the Conduit, go to:

<http://www.multitech.net/developer/software/aep/getting-started-aep/>

For help using DeviceHQ and Node-RED, go to <http://www.multitech.net/developer/software/devicehq/>

## Preparing the mDot Box

To get started with the mDot Box:

1. Attach a LoRa antenna to the mDot Box.
2. Insert the battery and power up mDot Box by pressing the switch on the left side.
3. When Select Mode appears, select **LoRa Demo**.
4. Select **Sw2** for **Interval**.  
By default the mDot Box will be sending data across the LoRa network every 10 seconds. Press SW2 for Interval to change the update.

The screen displays the sensor data as follows:

- Accelerometer x, y, and z axes
- Pressure
- Temperature
- Light

For more information on the mDot Box, refer to the enclosed MultiConnect mDot Box Quick Start or go to <http://www.multitech.net/developer/software/dot-box-and-evb-software/>

## Sending Data to the Cloud with IBM Bluemix

To send data from the mDot Box to the Cloud:





1. On your computer, use a web browser to go to <https://quickstart.internetofthings.ibmcloud.com/>
2. Check to select IBM's Terms of Use.
3. On your Conduit, find the product label with the **Node ID**, which is formatted as: 00:AB:EF:00:11:11
4. In the Device ID field, enter the **Node ID** using hyphens instead of the colons, for example 00-AB-EF-00-11-11
5. Click **Go**. Your data appears in the graphs.

**Note:** For secure data submission, create a Bluemix account. Data submitted to the IBM Bluemix Quickstart page is not private and can be accessed by any party possessing the machine address of your mDot Box.

## Using IBM Bluemix

- Click on the datapoints fields (temperature, light, etc) below the chart to view the corresponding chart.
- Creating a Bluemix account allows you to create a personalized application with safe data storage.

MTDOT-BOX/EVB	
Select Mode	
Survey single	
Survey sweep	
=> LoRa demo	
Configuration	
Scroll	Select
o	o
Left	Right



- A Bluemix account also gives you access to a variety of data storage and analytic tools.
- After creating an account on Bluemix for data storage, access the Conduit's Node-RED application and create a new output node to send data to your Bluemix account. Learn more about using Node-RED on the Conduit: [http://www.multitech.net/developer/wp-content/uploads/2015/08/DeviceHQ\\_Dev\\_User\\_Guide.pdf](http://www.multitech.net/developer/wp-content/uploads/2015/08/DeviceHQ_Dev_User_Guide.pdf).

## Related Documentation

### Quick Starts included in the Starter Kit

- MultiConnect Conduit
- MultiConnect mDot Box
- MultiConnect mDot Developer Kit
- MultiConnect mDot with Micro Developer Kit
- Accessory Card

## Developer Site and Manuals

Developer Guides, Dot Series AT Commands, and developer resources are available at [multitech.net](http://multitech.net). For specific product information go to:

- MultiConnect Conduit: <http://www.multitech.net/developer/products/conduit/>
- LoRa Accessory mCard: <http://www.multitech.net/developer/products/accessory-cards/mtac-lora/>
- MultiConnect mDot and Developer Kits: <http://www.multitech.net/developer/products/multiconnect-mdot/>
- MultiConnect mDot Box: <http://www.multitech.net/developer/products/multiconnect-mdot-box-and-evb/>
- LoRa Resources: <http://www.multitech.com/technology/lora>
- IBM Bluemix Resources for MultiConnect Conduit AEP, LoRa, and mDots: <https://developer.ibm.com/recipes/tutorials/multitech-multiconnect-conduit-aep-lora/>

## mBed

ARM® mbed is a free, open-source platform and operating system for embedded devices using the ARM Cortex-M microcontrollers. The mbed website provides free software libraries, hardware designs, and online tools for rapid prototyping of products. The platform includes a standards-based C/C++ SDK, a microcontroller HDK, and supported development boards, an online compiler and online developer collaboration tools.

- MultiConnect mDot and Developer Kits: <https://developer.mbed.org/platforms/MTS-mdot-f411/>
- MultiConnect mDot Box: <https://developer.mbed.org/platforms/mdotevb/>

## Support

Developer forums are available at <http://www.multitech.net/developer/forums/>.

If you need help, create an account and submit a support case directly to our technical support team, visit: <https://support.multitech.com>.