

Installing a SIM Card

To operate the device, you need a micro SIM card (3FF) from your network provider.

To install the SIM card:

1. Locate the SIM card slot on the device. It is labeled SIM.
2. Push the SIM card into the slot with the contact side facing up as shown. The SIM card locks into place.



Installing the Device

1. Install drivers on your computer. Go to <https://www.multitech.com/brands/multiconnect-microcell>, select your model, and click **Downloads**.
2. Connect antennas to the antenna connectors.
3. Connect the USB connector to your computer, either directly or through a hub.

The USB connection powers the device and the **POWER** LED lights.

Regulatory Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

For additional regulatory information, see your device's user guide or go to your device's page at <http://www.multitech.com>

MultiConnect® microCell Cellular Modem (MTCM2)

Document Part Number: 82104700L

Copyright and Trademarks

This publication may not be reproduced, in whole or in part, without the specific and express prior written permission signed by an executive officer of Multi-Tech Systems, Inc. All rights reserved. Copyright © 2020 by Multi-Tech Systems, Inc.

Multi-Tech Systems, Inc. makes no representations or warranties, whether express, implied or by estoppels, with respect to the content, information, material and recommendations herein and specifically disclaims any implied warranties of merchantability, fitness for any particular purpose and non-infringement. Multi-Tech Systems, Inc. reserves the right to revise this publication without obligation to notify any person or organization of such revisions or changes.

MultiConnect, MultiTech and the MultiTech logo are registered trademarks of Multi-Tech Systems, Inc. All other brand and product names are trademarks or registered trademarks of their respective companies.

Multi-Tech Systems, Inc

2205 Woodale Drive,
Mounds View, Minnesota 55112 U.S.A.

Phone: 763-785-3500 or 800-328-9717

Fax: 763-785-9874

Support

Support Portal

<https://support.multitech.com>

Europe, Middle East, Africa:

support@multitech.co.uk

+(44) 118 959 7774



Knowledge Base

<http://www.multitech.com/kb.go>

U.S., Canada, all others:


support@multitech.com

(800) 972-2439 or (763) 717-5863

Business Hours: M-F, 8am to 5pm CT



MultiConnect® microCell Cellular Modem MTCM2 Quick Start



Overview

The MultiConnect microCell (MTCM2) is a compact communications device that provides network capabilities for fixed and mobile applications.

Package Contents

Your package includes the following (varies with model):


Device	1- MultiConnect microCell modem
Antennas	2 - External antennas
Documents	1 - Quick Start, 1 - Warranty information

Documentation

To download documentation, go to <https://www.multitech.com/brands/multiconnect-microcell>, select your model and click **Manuals** for device specific documentation.

Document	Description
MultiConnect microCell User Guide	Hardware, regulatory, and getting started information.
MultiConnect microCell Quick Start	This document. Steps for getting started. Check online for an update version.
AT Commands Reference Manual	Lists AT Commands and parameters used to communicate with your device.

Side Panels



Connectors

The device has the following connectors:


- **USB** 1 USB connector,
- **SMA** 2 female SMA connectors, labeled CELL and AUX
- **SIM** 1 micro-SIM slot, between the SMA connectors

LEDs

Note:

- For additional LED information, refer to the User Guide for your model.
- Slow is 1 second, on 1 second off.
- Fast is 200 milliseconds, on 200 milliseconds off.

LED	Status	Description
Power	On	Device has power
	Off	Device does not have power
Link Status (LS)	On	Radio is not registered
	Flash Slow	Registered
	Off	Radio is turned off, in PSM mode, receiving a firmware update, or SIM is not inserted.
LTE	On	LTE
	Flash Fast	<i>L4G1 only</i> 3G
	Flash Slow	<i>L4G1 only</i> 2G
	Off	SIM not inserted or radio technology unknown
SIM	On	Ready
	Flash Slow	Other
	Off	SIM not inserted

LED	Status	Description
Signal Strength 	On	Good
	Flash Fast	Fair
	Flash Slow	Poor
	Off	Too low for communication or SIM not inserted.

Dimensions

With antennas attached, the dimensions are as follows. Refer to the user guide for more detailed dimensions.

